

1. Recommended minimum 18" clearance all around spa, unless otherwise specified.
2. If equipped, ozonator is located behind panel on the pump side.
3. Drain valve located behind panel on the pump side
4. ⑤ Indicates recommended electrical pass-through area for permanent wiring of 240v if converted. See routing & electrical suggestions.
5. See owners manual for complete locating , electrical and safety instructions.
6. Deck load: 160 psf
7. \*Cover lifter and step are part of suite package, available at time of spa purchase only.
8. \*Cover lifter is able to be placed on any side of the spa.

